



INSTANT ADHESIVE

See other installation options which may work better for the specific task

**** **We do not offer our safety padding with PSA (Pressure Sensitive or Peel/Stick Backing)** ****

BOING SAFETY - 4000

- Liquid gel in plastic bottle with squeeze applicator tip
- Very high strength bond - especially for rubber & plastic type products
- Does not work on all surfaces such as bare metals
- test before using
- Working time - up to 60 seconds
- Set/Cure time "after contact"- 20 seconds (depending on conditions and application)
- 1 oz bottle = 28 grams net weight
- 2 oz bottle = 56 grams net weight

Our quality is equal or superior to similar instant adhesives sold in retail stores



INSTALLATION

- Read safety instruction on bottle
 - Recommend you use vinyl or rubber gloves to prevent adhesive sticking to your fingers.
1. Test product in an inconspicuous area first to make sure it works as desired.
 2. If possible, use sandpaper to slightly roughen both surfaces for better adhesion
 3. Use isopropyl/denatured alcohol wipes to clean both surfaces
 4. Wait for alcohol to flash off
 5. You can attach with "spots" of adhesive for minimum hold
 6. You can attach with full surface coverage for maximum hold
 7. **DO NOT APPLY TOO THICK** or it will take much longer to bond
 8. For small pieces or short strips
 - apply adhesive on the complete product to be attached
 - be sure to get adhesive around outer edges
 - press into place and rub with fingers to ensure good adhesion
 9. For longer flexible strips (Slim V or Slim C) you can use different options - here is one example:
 - Anchoring: apply adhesive at one end of product - **especially around outer edges**
 - attach to surface and wait at least 20-30 seconds
 - add adhesive to the next 6-12" section of the padding
 - push strip up against surface and pull back and forth to spread the adhesive
 - attach to surface - press firmly
 - continue to add adhesive in 6-12" increments until completed
 - try not to leave any gaps on the strip with no adhesive
 - if necessary, you can go back and add some more adhesive to where you missed spaces

PREVENT NOZZLE CLOGGING

- after you have finished using the adhesive, hold the bottle upright and squeeze the sides.
- this allows the air to clear out the nozzle tip and to prevent it from crusting over.
- do not squeeze too hard or you will squirt out adhesive
- replace cap when you have expelled most of the air from the bottle

Effective 15 April, 2016

Boing product warranty on safety padding is voided if non-approved adhesive is used

Network USA Inc. Companies

136 Walker Street, Atlanta GA 30313
404-521-9054 Order 800-477-6434 Fax: 404-222-8366
www.BoingSafety.com info@BoingSafety.com

Silicone Solution - *For most applications*
Velcro Solution - *For removable applications*
Screw Solution - *For selected applications*